

SOLENOID DIRECTIONAL VALVE OVERRIDE OPTIONS

L	PULL STYPE (CABLE OPERATED)	H	PULL STYPE (HAND OPERATED)
<div data-bbox="624 264 852 315" data-label="Text">Last Code of Valve</div> <div data-bbox="624 315 852 367" data-label="Text">L Option</div> <div data-bbox="272 504 730 618" data-label="Text"> <p>Please note the pull force and without crooked direction. If you have any question, please contact Winner's sales department.</p> </div> <div data-bbox="384 618 751 945" data-label="Image"> </div> <div data-bbox="164 1001 831 1111" data-label="List-Group"> <ul style="list-style-type: none"> · If thread M5x0.8 is required, the last digit of the ordering code is -1. · If thread No.10-32UNF-2A is required, the last digit of the ordering code is -3. (For example, PEP-08W-07-L-0220-3) </div> <div data-bbox="604 1106 847 1173" data-label="Text"> <p>The appearance and the dimension are only for reference.</p> </div> <div data-bbox="156 1137 308 1173" data-label="Text"> <p>UNIT:mm</p> </div>		<div data-bbox="852 264 1326 315" data-label="Text">Last Code of Valve</div> <div data-bbox="852 315 1326 367" data-label="Text">H Option</div> <div data-bbox="919 369 1386 483" data-label="Text"> <p>Please note the pull force and without crooked direction. If you have any question, please contact Winner's sales department.</p> </div> <div data-bbox="986 483 1560 992" data-label="Image"> </div> <div data-bbox="863 1001 1552 1111" data-label="List-Group"> <ul style="list-style-type: none"> · If thread M5x0.8 is required, the last digit of the ordering code is -1. · If thread No.10-32UNF-2A is required, the last digit of the ordering code is -3. (For example, PEP-08W-07-H-0220-3) </div> <div data-bbox="1302 1106 1568 1173" data-label="Text"> <p>The appearance and the dimension are only for reference.</p> </div> <div data-bbox="855 1137 1010 1173" data-label="Text"> <p>UNIT:mm</p> </div>	